



## YOUR CHECKLIST

We urge you to take the following precautions before using the machine each day.

### 1. Visual inspection around the machine (only when unhitched)

- External damage! The machine must not show any damage
- Safety pins! All safety pins on the lower and upper hitches must be intact to securely hitch the machine to the tractor
- Screwed components! All screwed components must be securely tightened
- Wheels! The wheels, whether rubber or metal, must not show any damage
- Protective covers! All safety covers (gearbox, belts, drive shaft, hexagonal shaft, including inspection hatches and chain guards) must be fully installed
- Oil leaks! Check for oil leaks around the machine
- External damage! The machine must not show any damage
- Piktograms! Safety signs and piktograms must always be complete, intact, and clearly legible

### 2. Visual inspection under the machine (only with the machine unhitched)

- Oil leaks! Are there any oil leaks under the machine?
- Blades! The cutting elements must be complete and in good condition
- Cleanliness! The machine must be free of debris or mulch residue to prevent the risk of ejection

### 3. Weather and Environmental Conditions

- Visibility! Do not operate the machine before or after sunrise
- Weather conditions! Do not operate the machine in conditions of reduced visibility (heavy rain, darkness, or fog)
- Temperatures! Even extreme cold poses significant hazards. Never operate the machine below freezing temperature – See the user manual
- Stability! Do not operate the machine on unstable ground
- Danger of projectiles! Clear the work area of stones, steel wire scraps, construction debris, or pieces of wood, as these pose a high risk of projectiles